
V200 POSITIONER

SPARE PARTS

V200 EX



VALVE ACCESSORIES & CONTROLS, INC.

V200EX Electropneumatic Positioner

Item	Description	Part No.	Qty
1	Housing		1
2	Feedback Arm Assembly	4091002	1
3	Feedback Spring Assembly 3-15 PSI	4091018	1
	Feedback Spring Assembly 6-30 PSI	4091019	1
4	Membrane Plate Assembly	4090081	1
5-8	Membrane piston, Membrane, washer, screw		1
	(included in #4)		1
9	Balance Arm (included in #4)		1
10	Screw ISO 1207 M4x8 (included in #4)		2
11	Guide Pin (included in #2)	4090024	1
12	Screw ISO 1207 M4x14		2
13	Cam	Varies	1
14	Cam nut and screw	4090030	1
15	Indicator screw		1
17	Indicator Arrow	4090049	1
18	Front cover assembly	4091001	1
19	Indicator cover o-ring	4090039	1
20	Indicator Cover Flat	4090038	1
21	Front Cover O-ring Nitrile	4092002	1
22	Pilot Valve (SG/LB)	4091010	1
22	Pilot Valve HG (High Gain)	4091008	1
22	Pilot Valve (SHGHF) Super High Gain High Flw	4091011	1
23,24	Top Cover Plate with screw	4090080	1
30-33	Filter Cover Plate Assembly	4090032	1
37	Drive Shaft	4090029	1
38	Spindle	Varies	1
41	1/4” I/P Plug”	400261	1
42	Bug screen/Silencer	400149	1
43	1/8” plastic gauge plug	4090618	4
45	Blind Plug	4093017	1
50	Zero Plug	4090037	1
52	Dome Indicator Kit (yellow/black)	4093008	1
52	Dome Indicator Kit (red/green)	4093010	1
53	EX I/P converter	4091006	1
54	E to P Conversion Plate	4091000	1

**Cams with other ranges, Front labels with other scale readings and
Drives suitable for the most frequently used actuator types are available